

INSTRUCTIONS



Fits all Hi-Point Firearms pistol grips and carbine pistol grips.

Make certain that your firearm is unloaded by visually and physically inspecting it in accordance with the Hi-Point's instructions and basic firearm safety rules.



Step 1

Fold or roll the grip cover from top to approx 1/3 of the grip cover downwards.



Step 2

Stretch the rolled grip cover over base of grip using both hands to pull



Step 3

Roll grip cover upwards.



Step 4

The grip cover is in position. Ensure that the cover is clear of the magazine release. Adjust as needed.

How to Remove

Removal is the opposite and can be performed by rolling the grip cover downwards until near end of gun grip. Then stretching the grip cover outward and pulling off the grip.



Made By



TUFF1.com
1-888-998-8331